

The electrician is required to label all secondary wires terminated on MVEA equipment with the numeric street address.

The electrician's responsibility is to dig underneath and feed wire up from the bottom and bury at NEC required depth.

All trenching must be backfilled and compacted around equipment.

